PT8232

Heavy Industrial • RS232

Absolute Linear Position to 60 inches (1524 mm) **Aluminum or Stainless Steel Enclosure Options VLS Option To Prevent Free-Release Damage IP67 • NEMA6 Protection**

GENERAL

Full Stroke Ranges	0-2 to 0-60 inches					
Electrical Interface		RS232				
Format		HEX				
Accuracy	± (0.25% to ± 0.10% full stroke				
Repeatability		± 0.02% full stroke				
Resolution		± 0.003% full stroke				
Measuring Cable	stair	stainless steel or thermoplastic				
Enclosure Material	powder-painted a	painted aluminum or stainless steel				
Sensor	plastic-hybr	id precision potentiometer				
Potentiometer Cycle Life		see ordering information				
Maximum Retraction Accel	eration	see ordering information				
Weight, Aluminum (Stainle	ss Steel) Enclosure	3 lbs. (6 lbs.), max.				


ELECTRICAL

Input Voltage	922 VDC
Input Current	40 mA
Baud Rate	9600 (selectable to 38.4K)
Update Rate	32 msec

ENVIRONMENTAL

Environmental Suitability	NEMA 4X/6, IP 67
Operating Temperature	-40° to 200°F (-40° to 90°C)
Vibration	up to 10 g's to 2000 Hz maximum





The PT8232 delivers position feedback via RS232 serial communication to your data acquisition or controller system. The PT8232 sends a raw 16-bit count from 0000H to FFFFH. Additionally this device can be set to continuously send data or send data only when polled.

As the internal position sensing element is a precision potentiometer, this transducer maintains current accurate position even during power loss and does not need to be reset to a "home" position.

Output Signal:






20630 Plummer Street • Chatsworth, CA 91311



I/O Format:

Data Format



Data Frame

6 byte Hex string:

STX	CMD	B ₀	B ₁	B ₂	ETX	
STX = 0x02	CMD = Con	nmand Code*	Bo - Bo =	Data Field*	ETX = 0x03	

Important! All communications to/from the transducer are in HEX!

User Commands:

			Sensor F	Response				
Description	<cmd></cmd>	<b<sub>0></b<sub>	<b<sub>1></b<sub>	<b<sub>2></b<sub>	<cmd></cmd>	<b<sub>0></b<sub>	<b<sub>1></b<sub>	<b<sub>2></b<sub>
Get Sensor Info	0x05	0x00	0x00	0x00	0x05	version ⁽⁴⁾	date ⁽⁵⁾	date ⁽⁵⁾
Get Serial Number	0x15	0x00	0x00	0x00	0x15	se	rial number ⁽	3)
Start Continuous Data	0x25	0x00	0x00	0x00	0x25	0x00	0x00	0x00
Stop Continuous Data	0x35	0x00	0x00	0x00	0x35	0x00	0x00	0x00
Get Position Data	0x45	0x00	0x00	0x00	0x45	$CMC^{(1)}$	$CMC^{(1)}$	status ⁽²⁾

(1)CMC - Current Measurement Count (Position)

The Current Measurement Count (CMC) is the output data that indicates the present position of the measuring cable.

The CMC is a 16-bit value that occupies the first two bytes $(B_0 \text{ and } B_1)$ of the data field. B_0 is the MSB (most significant byte) and B₁ is the LSB (least significant byte).

The CMC starts at 0000H with the measuring cable fully retracted and continues upward to the end of the stroke range stopping at FFFFH. This holds true for all ranges.

(2)Status

The status byte is used as a flag to indicate the validity of the position signal that the internal electronics receives from the potentiometer.

Flags are as follows: 0x00 = GREEN, 0x55 = YELLOW, 0xAA = RED

A "green" flag shows everything OK. A "yellow" or "red" flag indicates that the sensor has either been extended beyond its range or that there is a problem with the potentiometer.

(3)Serial Number

Each sensor has it's own unique serial number. This information can be retrieved by sending the sensor the "Get Serial Number" command.

The serial number is a 3 byte value from which ranges from 0 to 9999999 (decimal).

(4) Version

This is a single byte value (0-255 decimal) which indicates the currently installed firmware version of the sensor.

(5) Date

This is a 2 byte value showing the date of currently installed firmware. This value ranges from 01011 -12319 (decimal). Format is MMDDY. While the month and day are expressed as two digit numbers the year is expressed in a single digit only.


Example: 08054 = August 5, 2004

Baud Rate

The baud rate can be set using switches 7 & 8 on the 8-pole DIP switch found on the rs232 controller board located inside the transducer.

DIP-7	DIP-8	baud rate
0	0	9600
1	0	19200
0	1	38400
1	1	9600






to gain access to the controller board, remove four Allen-Head Screws and remove rear cover.

PT8232





Ordering Information:

Model Number:



Sample Model Number:

PT8232 - 50 - AL - N34 - T1 - CG - M6

R range: A enclosure

aluminum .034 nylon-coated stainless measuring cable:

measuring cable tension: standard

① cable guide: standard electrical connection: 6-pin plastic connector

Full Stroke Range:

order code:	2		5		10		15		20		25		30		40		50		60
full stroke range, min:	2 in.	:	5 in.	:	10 in.	:	15 in.	:	20 in.	:	25 in.	:	30 in.	:	40 in.	:	50	:	60
accuracy (% of f.s.):	0.25%	:	0.25%	:	0.15%		0.15%	:	0.15%	:	0.15%	:	0.15%		0.10%	:	0.10%	:	0.10%
potentiometer cycle life*:	2.5×10^6	:	2.5×10^{6}	:	5 x 10 ⁵		5 x 10 ⁵		5 x 10 ⁵	:	5 x 10 ⁵	:	5 x 10 ⁵		2.5×10^5	:	2.5 x 10 ⁵	:	2.5 x 10 ⁵

^{*–1} cycle is defined as the travel of the measuring cable from full retraction to full extension and back to full retraction

Enclosure Material:

316 A order code: powder-painted aluminum 303 stainless steel 316 stainless steel

Measuring Cable:

N34 **S47** V62 B order code: Ø.062-inch thermoplastic Ø.034-inch nylon-coated stainless steel Ø.047-inch stainless steel available in all ranges 5, 15, 20, 25, 30-inch ranges only all ranges up to 30 inches only

Ordering Information (cont.):

Measurina Cable Tension:

	(order code:	T1		T2		Т3
		standard tension	÷	medium tension	:	high tension
	2, 10-inch:	39 oz.		65 oz.		116 oz.
full stroke range	15-inch:	26 oz.		43 oz.		77 oz.
cable tension	20, 40-inch:	20 oz.		33 oz.		60 oz.
specifications	5, 25, 50-inch:	16 oz.		26 oz.		47 oz.
	30, 60-inch:	13 oz.		22 oz.		40 oz.
	_					tension tolerance: ± 50%
		maximum acceleration		maximum acceleration		maximum acceleration
а	luminum enclosure:	15 g		25 g	:	40 g
stain	less steel enclosure:	6 g		12 g		18 g

Cable Guide Options:

Order code:

CG

SS

CB*

BR

Standard cable guide


stainless steel cable guide

polyurethane cable guide

integral cable brush

i.i.





北京赛斯维测控技术有限公司 北京市朝阳区望京西路48号

金隅国际C座1002

电话: +86 010 8477 5646 传真: +86 010 5894 9029 邮箱: <u>sales@sensorway.cn</u> http://www.sensorway.cn

version: 6.0 last updated: November 5, 2012

*note: all ranges up to 25 inches only